
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness
ID1	Roof No.2 Wire and Cowl Wire
IE3	Lamp Wire and Cowl Wire
IF1	Cowl Wire and Cowl No.2 Wire
IG1	Front Door LH Wire and Lamp Wire
IH1	Instrument Panel Wire and Cowl Wire
IH2	
IH3	
IH4	