
# Connector Joining Wire Harness and Wire Harness




| Code | Joining Wire Harness and Wire Harness |
|---|---|
| ID2 | Roof No.2 Wire and Cowl Wire |
| IE2 | Lamp Wire and Cowl Wire |
| IF1 | Cowl Wire and Cowl No.2 Wire |
| IG1 | Front Door RH Wire and Lamp Wire |
| IH1 | Instrument Panel Wire and Cowl Wire |
| IH2 | |
| IH3 | |
| IH4 | |