

Door Lock Control (Emergency Door)
Power Source
E16 EMERGENCY DOOR LIGHT
D17 DOOR LOCK RELAY
LOCK UNLOCK
D15 DOOR LOCK CONTROL RELAY
D16 DOOR LOCK MOTOR
Behind the rear combination light LH
Near the license plate light
Floor cross member No. 2 center
10A GAUGE
EMERG DOOR RELAY
From Exit Warning Light[Comb. Meter] <29–2>
I 3 IGNITION SW
ACC
IG1
ST1
AM1
F16 FUSE BLOCK
60A AM1
100A ALT
15A EM–DR
FL MAIN 3. 0W
BATTERY
BATTERY