

Front Fog Light
Back–Up Light
Power Source
15A FOG
FR FOG RELAY
F21 FRONT FOG LIGHT RH
F20 FRONT FOG LIGHT LH
J 8 JUNCTION CONNECTOR
Instrument panel right
C 6 FRONT FOG LIGHT SW [COMB. SW]
J 7 JUNCTION CONNECTOR
Instrument panel left
TAIL RELAY
See Taillight System<6–1>
15A TAIL
B 1 BACK–UP LIGHT SW
R18 REVERSE WARNING BUZZER
BUZZER
R 8 BACK–UP LIGHT RH [REAR COMB. LIGHT RH]
R 7 BACK–UP LIGHT LH [REAR COMB. LIGHT LH]
Behind the rear combination light RH
Behind the rear combination light LH
10A GAUGE
I 3 IGNITION SW
ACC
IG1
ST1
AM1
F16 FUSE BLOCK
60A AM1
120A ALT
50A AM FR
FL MAIN 3. 0W
BATTERY