# MODEL CODE

## MODEL CODE

**B B 4 0 R - Z E M R S Q**

① ② ③ ④ ⑤ ⑥ ⑦ ⑧

| ① BASIC MODEL CODE |
|---|
| BB40 : With 3B Engine |
| BB42 : With 14B Engine |
| HZB50 : With 1HZ Engine |

| ② STEERING POSITION |
|---|
| R : Right-Hand Drive |
| L : Left-Hand Drive |

| ③ ROOF TYPE |
|---|
| B : Standard |
| Z : High |

| ④ SEATING CAPACITY |
|---|
| C : 17, 19 or 20 |
| E : 19 or 22 |
| R : 26 |
| G : 30 |

| ⑤ GEARSHIFT TYPE |
|---|
| M : 5-Speed Manual, Floor |
| P : 4-Speed Automatic, Floor |

| ⑥ GRADE |
|---|
| R : STD |
| S : STD (with Cooler) |
| N : DX |
| Q : EX |

| ⑦ ENGINE TYPE |
|---|
| S : Diesel |

| ⑧ DESTINATION |
|---|
| Q : Australia |
| V : G.C.C. Countries |
| blank : General Countries or Hong Kong |