■ SEAT BELTS

1. General

The table below shows seat belt availability.


○ : Standard ● : Option

Destination / Seat Belt		Australia	G.C.C. Countries	Hong Kong	General Countries
Driver	3-Point ELR*1	○	○	○	–
	2-Point NR*2	–	●	–	●
Passengers	3-Point ELR	○	–	–	–
	2-Point NR	–	●	–	–

*1 ELR (Emergency Locking Retractor)
*2 NR (Non-Retractor)

2. Driver's Seat Belt


The driver's seat belt inner buckle is attached to the seat cushion. The buckle moves with the seat itself.



Seat Belt Inner Buckle

3. Passenger's Seat Belt

The seat belt inner buckle, which is attached to the seat cushion frame, can be retracted in to the cushion when it is not being used.



Seat Belt Inner Buckle