MODEL CODE

HZB50 R – Z E M R S Q

1 2 3 4 5 6 7 8

1 BASIC MODEL CODE

CODE	ENGINE	WHEEL BASE
RZB40	3RZ-FE	Short
RZB50		Long
BB42	14B	Short
BB50	15B-FT	Long
BB58	15B-FTE	
BB59		Super Long
BZB40	1BZ-FPE	Short
HZB50	1HZ	Long

2 STEERING WHEEL POSITION

L: Left-Hand Drive
R: Right-Hand Drive

3 ROOF TYPE

B: Standard Roof
Z: High Roof

4 SEATING CAPACITY

C:17 or 20
F: 19, 20, 22 or 23
G: 30
R: 26

5 GEAR SHIFT TYPE

F : 6-Speed Manual, Floor
M : 5-Speed Manual, Floor

6 GRADE

N : DX
R : Standard (Without Air Conditioner)
D : Standard (With Air Conditioner)
Q : EX

7 ENGINE SPECIFICATION

C : LPG
K : EFI
S : Diesel
W : Diesel, Turbocharger
Z : FEI Diesel, Turbocharger

8 DESTINATION

Q : Australia
V : G.C.C. Countries
C : China
Blank : General Countries

8 CHASSIS MODEL / COMPLETE MODEL

5 : Super Long, Seat Less Model
Blank : Complete Model