MODEL CODE

XZB50 L – Z R M S Y W 1

1 2 3 4 5 6 7 8 9

1 BASIC MODEL CODE

CODE	ENGINE	WHEEL BASE
XZB50	N04C-TQ	Long
XZB59		Super Long
BZB40	1BZ-FPE	Standard
BZB50		Long
BB42	14B	Standard
BB50	15B-FT	Long
HZB50	1HZ	
RZB40	3RZ-FE	Standard
RZB50		Long

2 STEERING WHEEL POSITION

R: Right-hand Drive
L: Left-hand Drive

3 ROOF TYPE

B: Standard Roof
Z: High Roof

4 SEATING CAPACITY

R: 26
E: 20, 22
C: 17
G: 30

5 GEAR SHIFT TYPE

M: 5-speed Manual, Floor

6 GRADE

R: Standard (Without Air Conditioner)
S: Standard (With Air Conditioner)
N: DX (With Air Conditioner)
Q: EX

7 ENGINE SPECIFICATION

S: Diesel
W: Diesel, Turbocharger
K: DOHC and EFI
C: LPG
Y: Common-rail, Diesel

8 DESTINATION

W: Europe
Q: Australia
V: G.C.C. Countries
R: Taiwan
Blank: General Countries

9 CHASSIS MODEL/COMPLETE MODEL

1: Chassis with Windshield Model
5: Super Long, Seatless Model
Blank: Complete Model