MODEL CODE

XZB50 L – Z R M S Y W 1

1 2 3 4 5 6 7 8 9

1	BASIC MODEL CODE		
	CODE	ENGINE	WHEEL BASE
	XZB40	N04C-UH	Standard
	XZB50		Long
	XZB59		Super Long
	BZB40	1BZ-FPE	Standard
	BZB50		Long
	BB42	14B	Standard
	BB50	15B-FT	Long
	HZB50	1HZ	
	TRB40	2TR-FE	Standard
	TRB50		Long

2	STEERING WHEEL POSITION
	R: Right-hand Drive L: Left-hand Drive

3	ROOF TYPE
	B: Standard Roof Z: High Roof

4	SEATING CAPACITY
	R: 26 E: 20, 21 C: 17 G: 30

5	GEAR SHIFT TYPE
	M: 5-speed Manual, Floor P: 4-speed Automatic, Floor

6	GRADE
	R: Standard (Without Air Conditioner) S: Standard (With Air Conditioner) N: DX (With Air Conditioner) Q: EX

7	ENGINE SPECIFICATION
	S: Diesel W: Diesel, Turbocharger K: DOHC and EFI C: LPG Y: Common-rail, Diesel

8	DESTINATION
	W: Europe Q: Australia V: G.C.C. Countries R: Taiwan Blank: General Countries

9	CHASSIS MODEL/COMPLETE MODEL
	1: Chassis Model 5: Super Long, Seatless Model Blank: Complete Model