MODEL CODE

BZB70 R – Z C M S C _ 5

1 2 3 4 5 6 7 8 9

	BASIC MODEL CODE[K1]		
	CODE [K2]	ENGINE	WHEEL BASE
1	XZB60	N04C-UH or N04C-VL or N04C-VQ [K3]	Standard
	XZB70		Long
	BZB60	1BZ-FPE	Standard
	BZB70		Long
	BB60	14B	Standard
	HZB70	1HZ	Long
	TRB60	2TR-FE	Standard
	TRB70		Long

	STEERING WHEEL POSITION
2	R: Right-hand Drive L: Left-hand Drive

	ROOF TYPE[K4]
3	Z: High Roof

	SEATING CAPACITY
4	C: 17 E: 20, 21, 22 G: 23, 29, 30 R: 20, 26 X: 19, 25

	GEAR SHIFT TYPE
5	M: 5-speed Manual, Floor P: 4-speed Automatic, Floor

	GRADE
6	R: Standard (without Air Conditioner) S: Standard (with Air Conditioner) N: DX (with Air Conditioner) Q: EX

	ENGINE SPECIFICATION
7	S: Diesel K: DOHC and EFI C: LPG Y: Common-rail, Diesel

	DESTINATION
8	Q: Australia V: G.C.C. Countries R: Taiwan Blank: General Countries

	COMPLETENESS CLASSIFICATION
9	5: [K5]Seatless Model Blank: Complete Model