

■ LAYOUT OF MAIN COMPONENTS




Text in Illustration

*A	Models with ABS	-	-
*1	ECM	*2	Exhaust Brake Solenoid with Bracket Assembly
*3	Intake Mass Air Flow Meter Sub-Assembly · Atmospheric Temperature Sensor	*4	EDU
*5	Brake Actuator Assembly · Skid Control ECU	-	-



Text in Illustration

*1	Turbocharger Sub-assembly	*2	Exhaust Retarder Assembly
*3	Engine Coolant Temperature Sensor	*4	Cam Position Sensor
*5	Injector Assembly	*6	Crankshaft Position Sensor
*7	Injection or Supply Pump Assembly	*8	Venturi Assembly · Throttle Position Sensor
*9	Turbo Pressure Sensor	*10	EGR Valve Assembly
*11	Common Rail Assembly	*12	Intake Air Temperature Sensor



Text in Illustration

*A	Models with SRS Airbag System	*B	Models with Network Gateway ECU
*C	Models with Air Conditioner	*D	Models with ABS
*E	Models without SRS Airbag System	-	-
*1	Combination Meter Assembly	*2	Clutch Pedal Switch (Exhaust Retarder Switch Assembly)
*3	DLC3	*4	Stop Light Switch Assembly
*5	Accelerator Pedal Position Sensor	*6	Airbag ECU Assembly
*7	Network Gateway ECU	*8	Air Conditioner Amplifier Assembly
*9	Exhaust Retarder Switch (Windshield Wiper Switch Assembly)	*10	Spiral Cable with Senor Sub-assembly · Steering Angle Sensor
*11	Yawrate Sensor	-	-