
■ THROTTLE CONTROL

- The opening of the throttle valve is controlled by the ECM in accordance with the engine conditions. As a result, the noise that is generated during idling and deceleration, as well as the noise and vibration that are generated when the engine is stopped, has been reduced.
- The throttle control prevents overrunning and vibrations when stopping the engine.



271EG140