■ DIAGNOSIS

- If a malfunction occurs on a CAN communication bus, ECUs that are connected to the CAN communication bus store Diagnostic Trouble Codes (DTCs) in memory.
- The DTCs can be read by connecting the Global TechStream (GTS) to the DLC3.
- For details, refer to the Repair Manual.