DOOR LOCK CONTROL SYSTEM

■ GENERAL

- The power door lock system is provided as standard for models for Australia and general countries which are equipped with a gliding type center door.
- The driver's door and gliding type center door can be locked/unlocked with the power door lock system.
- The door control relay is installed in the passenger seat side of the instrument panel.
- The door lock control switch is installed in the driver side of the instrument panel.
- IG ON unlock system has been provided depending on the specifications.