

DESCRIPTION

PR03A-01
The propeller shaft is connected to the transmission and the differential via 3 (Short Body) and 4 (Long Body) joints.

Short Body



Long Body



R05666
R05667

Z07281