

PREPARATION

SST (SPECIAL SERVICE TOOLS)

SA0WK-01

	09218–56030 Cylinder Liner Remover & Replacer	
	09308–00010 Oil Seal Puller	
	09316–60010 Transmission & Transfer Bearing Replacer	
	(09316–00010) Replacer Pipe	
	(09316–00060) Replacer "E"	
	* 09608–20012 *Front Hub & Drive Pinion Bearing* Tool Set	
	(09608–03020) Handle	
	(09608–03060) Replacer	
	09628–62011 Ball Joint Puller	
	09751–36011 Brake Tube Union Nut 10 x 12 mm Wrench	

SA06K-02

EQUIPMENT

Dial indicator	
Torque wrench	
Spring tension gauge	

SA