GENERAL DESCRIPTION

SR01E-03

- **Care must be taken to replace parts properly because they could affect the performance of the steering system and result in a driving hazard.**

TROUBLESHOOTING

SR003-04

Use the table below to help you find the cause of the problem.
The numbers indicate the priority of the likely cause of the problem. Check each parts in order. If necessary, replace these parts.

See page / Parts Name / Trouble	Tires (Improperly inflated)	Front wheel alignment (Incorrect)	Fluid level (Low)	Steering system joints (Worn)	Suspension arm ball joints (Worn)	Steering column (Binding)	Sliding yoke (Worn)	Steering gear housing	Front wheel bearing (Worn)
See page	SA-3	SA-3	SR-25	–	SA-37	–	–	SR-50	SA-10
Hard steering	1	4	2	5	6	7		8	
Poor return	1	2				3		4	
Excessive play				1	2		3	5	4
Abnormal noise			1	2				3	

V03340