



PREPARATION


SST (SPECIAL SERVICE TOOLS)

SR02B-05

	09527–10011	Rear Axle Shaft Bearing Remover	
	09610–20012	Pitman Arm Puller	
	09612–22011	Tilt Handle Bearing Replacer	
	09616–00010	Steering Worm Bearing Adjusting Socket	
	09630–24013	Steering Rack Oil Seal Tool Set	
	(09620–24020)	Valve Cup Oil Seal Replacer	
	09632–36010	Steering Vane Pump Bearing Replacer	

RECOMMENDED TOOLS

SR01P-05

	09025–00010	Small Torque Wrench	For measuring preload
	09905–00013	Snap Ring Pliers	

SR

SR027-03

EQUIPMENT

Belt tension gauge	
Calipers	
Dial indicator	
Micrometer	
Oil pressure gauge	
Torque wrench	
Vacuum gauge	

SR028-03

LUBRICANT

Item	Capacity	Classification
Power steering fluid	—	ATF DEXRON® II