



PREPARATION

SST (SPECIAL SERVICE TOOLS)

	09032–00100 Oil Pan Seal Cutter	
	09213–54015 Crankshaft Pulley Holding Tool	
	09223–50010 Crankshaft Front oil Seal Replacer	Crankshaft front oil seal
	09228–07500 Oil Filter Wrench	
	09330–00021 Companion Flange Holding Tool	Crankshaft pulley
	09636–20010 Upper Ball Joint Dust Cover Replacer	
	09950–40010 Puller B Set	
	(09951–04010) Hanger 150	
	(09952–04010) Slide Arm	
	(09953–04010) Center Bolt 100	
	(09954–04010) Arm 25	
	(09955–04060) Claw No.6	
	09950–50010 Puller C Set	

	(09951–05010) Hanger 150	
	(09952–05010) Slide Arm	
	(09953–05010) Center Bolt 100	
	(09954–05020) Claw No.2	

RECOMMENDED TOOLS

	09200–00010 Engine Adjust Kit	

EQUIPMENT

Oil pressure gauge	
Precision straight edge	Oil pump
Torque wrench	

LUBRICANT

Item	Capacity	Classification
Engine oil		API grade SG, SH or ILSAC multigrade engine oil and recommended viscosity oil
RCK series		
Dry fill	6.0 liters (6.3 US qts, 5.3 Imp. qts)	
Drain and refill		
w/ Oil filter change	5.5 liters (5.8 US qts, 4.8 Imp. qts)	
w/o Oil filter change	4.8 liters (5.1 US qts, 4.2 Imp. qts)	
RZB series		
Dry fill	6.0 liters (6.3 US qts, 5.3 Imp. qts)	
Drain and refill		
w/ Oil filter change	5.2 liters (5.5 US qts, 4.6 Imp. qts)	
w/o Oil filter change	4.5 liters (4.8 US qts, 4.0 Imp. qts)	

SSM (SPECIAL SERVICE MATERIALS)

E0077-03

08826—00080	Seal packing or equivalent	Oil pump Oil pan (Timing chain cover)
08833—00080	Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Oil pressure switch