ABBREVIATIONS USED IN THIS MANUAL

IN

A/C	Air Conditioner
ACSD	Automatic Cold Start Device
Approx.	Approximately
A/T	Automatic Transmission
BDC	Bottom Dead Center
FL	Fusible Link
FIPG	Formed in Place Gasket
LST	Load Sensing Timer
MP	Multipurpose
M/T	Manual Transmission
OHC	Over Head Camshaft
O/S	Oversized
PCV	Positive Crankcase Ventilation
RHD	Right–Hand Drive
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TDC	Top Dead Center
U/S	Undersize
W	With