






















STEERING

PP2CB–01

SST (Special Service Tools)

	09610–20012	Pitman Arm Puller	PS gear
	09612–22011	Tilt Handle Bearing Replacer	PS vane pump
	09616–00010	Steering Worm Bearing Adjusting Socket	PS gear
	09630–00014	Power Steering Gear Housing Overhaul Tool Set	
	(09631–00051)	No.3 Wrench	PS gear
	(09631–00142)	Overhaul Stand	PS gear
	09631–22020	Power Steering Hose Nut 14 x 17 mm Wrench Set	PS gear
	09950–30011	Puller A Set	
	(09951–03010)	Upper Plate	PS vane pump
	(09953–03010)	Center Bolt	PS vane pump
	(09954–03010)	Arm	PS vane pump
	(09955–03020)	Claw No.2	

	09950–40011	Puller B Set	
	(09951–04020)	Hanger 200	PS gear
	(09952–04010)	Slide Arm	PS gear
	(09953–04020)	Center Bolt 150	PS gear
	(09954–04010)	Arm 25	PS gear
	(09955–04031)	Claw No.3	PS gear
	(09958–04011)	Holder	PS gear
	09950–50012	Puller C Set	
	(09951–05010)	Hanger 150	Tilt steering column
	(09952–05010)	Slide Arm	Tilt steering column
	(09953–05020)	Center Bolt 150	Tilt steering column
	(09954–05020)	Claw No.2	Tilt steering column
	09950–60010	Replacer Set	

	(09951–00300) Replacer 30	PS vane pump
	09950–70010 Handle Set	
	(09951–07100) Handle 100	PS vane pump