
POWER STEERING VANE PUMP

COMPONENTS


SR0Y2–01



N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
⇦ Power steering fluid

P

F10074


Front Housing
Vane Pump Shaft
◆ Oil Seal
◆ Snap Ring
◆ O–ring
19 (194, 14)
Spring
Flow Control Valve
◆ Bearing
◆ Snap Ring
Suction Port Union
◆ O–ring
Vane Pump Drive Gear
Pressure Port Union
69 (700, 51)
Cam Ring
◆ Straight Pin
◆ Snap Ring
Rear Housing
◆ O–ring
◆ O–ring
x 10
Vane Plate
Vane Pump Rotor
Side Plate
◆ Wave Washer
N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
⇦ Power steering fluid
P
F10058