







# ENGINE MECHANICAL

PP2CL–01

## SST (Special Service Tools)

| | | | |
|---|---|---|---|
|  | 09202–70020 | Valve Spring Compressor | |
|  | (09202–00030) | Attachment | |
|  | (09202–00010) | Attachment | |
|  | (09202–01020) | Set Bolt | |
|  | (90154–80004) | Screw | |
|  | 09236–00101 | Water Pump Overhaul Tool Set | |
|  | (09236–15010) | Bearing Stay | Valve stem oil seal |
|  | 09243–00020 | Idle Adjusting Screw Wrench | |
|  | 09843–18020 | Diagnosis Check Wire | |
|  | 09960–10010 | Variable Pin Wrench Set | |
|  | (09962–01000) | Variable Pin Wrench Arm Assy | |
|  | (09963–01000) | Pin 10 | Exhaust camshaft sub–gear |

| | | |
|---|---|---|
|  | (09963–00500) Pin 5 | Exhaust camshaft sub–gear |
|  | (09963–01000) Pin 10 | Exhaust camshaft sub–gear |
|  | (09236–15010) Bearing Stay | Valve stem oil seal |