
AC3MW–01

REMOVAL

REMOVE CONDENSER FAN ASSEMBLIES

(a) Disconnect the condenser fan connector.



(b) Remove the 4 bolts and the condenser fan assembly.
(c) Remove the No. 1 and No. 2 condenser fan assemblies.