IDLE SPEED

EM1AN–02

INSPECTION

1. INITIAL CONDITIONS

(a) Air cleaner installed.
(b) Engine at normal operating temperature.
(c) All pipes and hoses of air induction system connected.
(d) All accessories switched OFF.
(e) All vacuum lines properly connected.

HINT:

All vacuum hoses should be properly connected.

(f) Ignition timing set correctly.
(g) Transmission in the N position.
(h) Air conditioning switched OFF.

2. CONNECT TACHOMETER

3. INSPECT IDLE SPEED

Idle speed: 700 ± 50 rpm

If not as specified, see page DI–4.