

CYLINDER HEAD

COMPONENTS

EM1UC–01




Valve Bridge
Pad
Keeper
Spring Retainer
Valve Spring
Spring Seat
◆ Oil Seal
Cylinder Head
◆ Valve Guide Bushing
Valve
◆ Non–reusable part
A17616