



# FUEL CUT SYSTEM

FU08E–02

## INSPECTION

### INSPECT FUEL CUT SYSTEM

(a) Increase the engine speed to at least 2,500 rpm.

(b) Using a sound scope, check the operating noise of the slow lock solenoid valve.

(c) Check that the operating noise of the slow lock solenoid valve occurs when releasing the throttle lever. Moments later, recheck that the noise is heard.