

(*2)
F24
G6
E31
F26
B10
E32
* 1:W04D-TN
* 2:N04C-VA, W04D-TM
H22
H15
H16
H17
H14
F22
N2
L4
O2
(*1)
B10
H10
H20
J54
H13
F20
H11
H12
B9
J53
J51
J52

B 9 Back-Up Light Switch Assembly
B 10 Back-Up Light Switch Assembly

E 31 Engine Oil Pressure Switch Assembly
E 32 Exhaust Brake with Bracket Solenoid Assembly

F 20 Fog Light Assembly LH
F 22 Fog Light Assembly RH
F 24 Front Wiper Motor & Bracket Assembly
F 26 Fuel Sender Gage Assembly

G 6 Glow Plug Assembly

H 10 Headlight Assembly LH
H 11 Headlight Assembly LH
H 12 Headlight Assembly LH
H 13 Headlight Assembly LH
H 14 Headlight Assembly RH
H 15 Headlight Assembly RH
H 16 Headlight Assembly RH
H 17 Headlight Assembly RH
H 20 Headlight Leveling Motor LH
H 22 Headlight Leveling Motor RH


J 51 Junction Connector
J 52 Junction Connector
J 53 Junction Connector
J 54 Junction Connector

L 4 Low Pitched Horn Assembly

N 2 No. 1 Pressure Switch

O 2 Option Connector (Power Outlet4)

B 9
Gray




B 10
Black




E 31
Black




E 32
Black



F 20
Black




F 22
Black



F 24
Black




F 26
Gray




G 6
Gray



H 10
Black



H 11
Black




H 12
Gray




H 13
Gray



H 14
Black



H 15
Black



H 16
Gray



H 17
Gray




H 20
Gray




H 22
Gray




J 51
White




J 52
Black




J 53
Gray




J 54
Gray



L 4
Black



N 2
Gray



O 2
Gray

