
Position of Parts in Instrument Panel

[LHD]



A 11 Accelerator Pedal Position Sensor
A 12 Ashtray Illumination

B 3 Blower Motor
B 4 Blower Resistor
B 5 Brake Fluid Level Warning SW
B 6 Brake Vacuum Warning Buzzer

C 4 Cigarette Lighter
C 5 Combination Meter
C 6 Combination Meter
C 7 Combination SW
C 8 Combination SW
C 9 Condenser Fan Fuse

D 1 Diode (A/C)
D 2 Diode (Pressure Charge Valve)
D 3 DLC3
D 4 Door Lock Control Relay

E 4 Engine ECU
E 5 Engine ECU
E 6 Engine ECU
E 7 Engine ECU
E 8 Exhaust Brake Accelerator Pedal SW
E 9 Exhaust Brake Clutch SW

F 11 Flasher Relay

H 7 Hazard SW
H 8 Headlight Beam Level Control SW
H 9 Heater Control SW