
Position of Parts in Instrument Panel

[LHD]



I 6 Ignition SW
I 11 Integration Relay

J 1 Junction Connector
J 2 Junction Connector
J 3 Junction Connector
J 4 Junction Connector
J 5 Junction Connector
J 6 Junction Connector
J 7 Junction Connector
J 8 Junction Connector
J 9 Junction Connector
J 10 Junction Connector
J 11 Junction Connector
J 12 Junction Connector
J 13 Junction Connector
J 14 Junction Connector
J 15 Junction Connector
J 16 Junction Connector
J 17 Junction Connector
J 18 Junction Connector
J 19 Junction Connector
J 20 Junction Connector
J 21 Junction Connector
J 22 Junction Connector
J 23 Junction Connector

P 5 PTO Clutch SW
P 6 PTO SW or Short Pin
P 14 Parking Light SW or Short Pin
P 15 Pre–Heating Timer

R 1 Radio and Player

S 15 Stop Light SW

T 3 Tachograph

W 3 Washer Motor