
Position of Parts in Body

[RHD]



A 4 Accel Position Sensor
A13 ABS Actuator
A14 ABS Actuator
A15 ABS Speed Sensor Rear LH
A16 ABS Speed Sensor Rear RH

D 5 Door Courtesy SW (Driver's Side)
D 6 Door Lock Control SW
D 7 Door Lock Motor (Passenger's Side)
D13 Door Courtesy SW (Passenger's Side)

F12 Front Side Turn Signal Light LH
F13 Front Side Turn Signal Light RH

I 7 Interior Light

L 1 License Plate Light LH
L 2 License Plate Light RH

P 7 Parking Brake SW
P 8 Power Outlet
P 9 Power Window Control SW (Passenger's Side)
P10 Power Window Master SW
P11 Power Window Motor (Driver's Side)
P12 Power Window Motor (Passenger's Side)
P16 Pretensioner (Driver's Side)

R 3 Rear Combination Light LH
R 4 Rear Combination Light RH
R 6 Reverse Warning Buzzer

S16 Speaker LH
S17 Speaker RH