
BRAKE

■ BRAKE CONTROL SYSTEM

EBD (Electronic Brake force Distribution) Function

The ABS (Anti-lock Brake System) function prevents the wheels from locking during braking. In addition to the ABS, an EBD (Electronic Brake force Distribution) function has been provided in order to distribute the braking force to the front and rear wheels through electronic control. This function optimally distributes the brake force to the front and rear wheels in accordance with the changes in the loading conditions. In particular, this function suppresses the early activation of the ABS function with a reduced load on the rear wheels, when the vehicle is empty. Thus, it increases the driver's brake control area.



▶ Fluid Pressure Control ◀

