















FUEL









PREPARATION








022E0–01

SST




	09023–12700	Union Nut Wrench 17mm	NOZZLE HOLDER AND NOZZLE SET(14B) INJECTION PUMP ASSY(14B) NOZZLE HOLDER AND NOZZLE SET(15B–FTE) INJECTION PUMP ASSY(15B–FTE)
	09228–10002	Oil Filter Wrench	DIESEL FUEL FILTER ASSY(14B) DIESEL FUEL FILTER ASSY(15B–FTE)
	09228–34010	Fuel Filter Wrench	DIESEL FUEL FILTER ASSY(S05C–B) DIESEL FUEL FILTER ASSY(S05C–TA) DIESEL FUEL FILTER ASSY(W04D–J)
	09228–64040	Fuel Filter Wrench	DIESEL FUEL FILTER ASSY(14B) DIESEL FUEL FILTER ASSY(15B–FTE)
	09228–78010	Oil Filter Wrench	DIESEL FUEL FILTER ASSY(S05C–TB)
	09236–00101	Water Pump Overhaul Tool Set	INJECTION PUMP ASSY(14B)
	(09237–00070)	Shaft ”C”	INJECTION PUMP ASSY(14B)
	09241–76022	Injection Pump Stand Set	INJECTION PUMP ASSY(14B)
	09245–54010	Injection Pump Stand Arm	INJECTION PUMP ASSY(14B)
	09260–54012	Injection Pump Tool Set	INJECTION PUMP ASSY(14B)
	(09262–54010)	Distributor Head Plug Wrench	INJECTION PUMP ASSY(14B)

	(09262–54020)	Regulator Valve Wrench	INJECTION PUMP ASSY(14B)
	(09269–54020)	Socket 14 mm	INJECTION PUMP ASSY(14B)
	(09269–54030)	Tweezers	INJECTION PUMP ASSY(14B) INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	(09269–54040)	Governor Lever Support Bolt Wrench	INJECTION PUMP ASSY(14B)
	09260–58010	Injection Pump Tool Set	INJECTION PUMP ASSY(14B)
	(09266–76011)	Automatic Timer Set Nut Wrench	INJECTION PUMP ASSY(14B)
	(09267–76011)	Automatic Timer Extractor	INJECTION PUMP ASSY(14B)
	(09278–46020)	Spring Shaft Holding Tool	INJECTION PUMP ASSY(14B)
	(09269–54030)	Tweezers	INJECTION PUMP ASSY(14B) INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	(09269–54050)	Pump Shaft Round Nut Wrench	INJECTION PUMP ASSY(W04D–J)
	(09272–76011)	Tappet Roller Clamp	INJECTION PUMP ASSY(W04D–J)
	(09273–76011)	Tappet Clamp	INJECTION PUMP ASSY(W04D–J)
	(09274–46011)	Plunger Clamp	INJECTION PUMP ASSY(W04D–J)

	(09275–46010) Plunger Clamp	INJECTION PUMP ASSY(W04D–J)
	(09280–46010) Plunger Spring Holder	INJECTION PUMP ASSY(W04D–J)
	(09287–58010) Injectiion Pump Camshaft Bearing Puller	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA) INJECTION PUMP ASSY(W04D–J)
	09950–40011 Puller B Set	INJECTION PUMP ASSY(W04D–J)
	09950–50013 Puller C Set	INJECTION PUMP ASSY(15B–FTE)
	(09951–05010) Hanger 150	INJECTION PUMP ASSY(15B–FTE)
	(09952–05010) Slide Arm	INJECTION PUMP ASSY(15B–FTE)
	(09953–05020) Center Bolt 150	INJECTION PUMP ASSY(15B–FTE)
	(09954–05021) Claw No.2	INJECTION PUMP ASSY(15B–FTE)
	S0951–01170 Injector Guide Rail	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	S0951–21150 Camshaft Clearance Gauge	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA) INJECTION PUMP ASSY(W04D–J)
	S0951–21410 Tapet Gap Instrument	INJECTION PUMP ASSY(W04D–J)
	S0951–21430 Outer Race Puller	INJECTION PUMP ASSY(W04D–J)

	S0951–21910	Injector Setting Support	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	(09287–58010)	Injectiion Pump Camshaft Bearing Puller	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA) INJECTION PUMP ASSY(W04D–J)
	S0951–21920	Delivery Valve Holder Remover	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	S0951–21930	Injector Spring Compressor	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	(09269–54030)	Tweezers	INJECTION PUMP ASSY(14B) INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	S0951–22100	Timing Setting	INJECTION PUMP ASSY(W04D–J)
	S0951–22210	Timer Wrench	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)
	S0951–22260	Governor Camshaft Bushing Extractor	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA)

Recomended Tools

	09040–00011	Hexagon Wrench Set	INJECTION PUMP ASSY(14B)
	09082–00040	TOYOTA Electrical Tester	INJECTION PUMP ASSY(14B) NOZZLE HOLDER AND NOZZLE SET(S05C–B) INJECTOR ASSY(S05C–TA) INJECTOR ASSY(S05C–TB)
	09200–00010	Engine Adjust Kit	INJECTION PUMP ASSY(14B)

Equipment

Angle gauge	
Dial indicator	
Injection pump tester	
Steel square	
Torque wrench	

Vacuum pump	
Vernier calipers	

SSM

08833–00070	”Adhesive 1324,” THREE BOND 1324 or equivalent	INJECTION PUMP ASSY(S05C–B) INJECTION PUMP ASSY(S05C–TA) INJECTION PUMP ASSY(W04D–J)