
















LUBRICATION


PREPARATION

022DZ–01

SST

	09032–00100	Oil Pan Seal Cutter	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	09213–58012	Crankshaft Pulley Holding Tool	OIL PUMP ASSY(14B)
	(90201–08131)	Washer	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(91111–50845)	Bolt	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	09213–58013	Crankshaft Pully Holding Tool	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(90201–08131)	Washer	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(91111–50845)	Bolt	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	09219–56010	Piston Cooler Remover	SUB–ASSY OIL NOZZLE NO.1(14B)
	09228–10002	Oil Filter Wrench	OIL FILTER SUB–ASSY(15B–FTE)
	09228–34010	Fuel Filter Wrench	OIL FILTER SUB–ASSY(S05C–B) OIL FILTER SUB–ASSY(W04D–J)
	09228–44011	Oil Filter Wrench	OIL FILTER SUB–ASSY(14B)
	09228–78010	Oil Filter Wrench	OIL FILTER SUB–ASSY(S05C–TA) OIL FILTER SUB–ASSY(S05C–TB)

	09330–00021	Companion Flange Holding Tool	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09963–00500)	Pin 5	OIL PUMP ASSY(15B–FTE)
	09608–06041	Front Hub Inner Bearing Cone Replacer	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	09950–50013	Puller C Set	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09951–05010)	Hanger 150	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09952–05010)	Slide Arm	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09953–05010)	Center Bolt 100	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09953–05020)	Center Bolt 150	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09954–05030)	Claw No.3	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	09960–10010	Variable Pin Wrench Set	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09962–01000)	Variable Pin Wrench Arm Assy	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	(09963–00500)	Pin 5	OIL PUMP ASSY(15B–FTE)
	(09963–01000)	Pin 10	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)

	(91111–50845)	Bolt	OIL PUMP ASSY(14B) OIL PUMP ASSY(15B–FTE)
	S0955–31010	Oil Filter Wrench	OIL FILTER SUB–ASSY(14B)

Equipment

Torque wrench	

SSM

08833–00080	Adhesive 1344 THREE BOND 1344 LOCTITE 242 or equivalent	OIL COOLER ASSY(14B) OIL PUMP ASSY(14B) OIL COOLER ASSY(15B–FTE) OIL PUMP ASSY(15B–FTE) OIL W/BRACKET COOLER ASSY(S05C–B) OIL W/BRACKET COOLER ASSY(S05C–TA) OIL W/BRACKET COOLER ASSY(S05C–TB) OIL COOLER ASSY(W04D–J)