






BRAKE



PREPARATION

022EE–01

SST

	09023–00100	Union Nut Wrench 10 mm	BRAKE FLUID BRAKE MASTER LESS RESERVOIR TANK CYLINDER SUB–ASSY REAR BRAKE ABS & TRACTION ACTUATOR ASSY
	09608–04031	Front Hub Inner Bearing Cone Replacer	VACUUM PUMP ASSY(14B, 15B–FTE) VACUUM PUMP ASSY(S05C–B, S05C–TA, S05C–TB)
	09703–30010	Brake Shoe Return Spring Tool	FRONT BRAKE REAR BRAKE
	09718–00010	Shoe Hold Down Spring Driver	FRONT BRAKE REAR BRAKE
	09737–00012	Brake Booster Push Rod Gauge	BRAKE MASTER LESS RESERVOIR TANK CYLINDER SUB–ASSY
	09751–36011	Brake Line Union Nut 10 x 12 mm Wrench	LOAD SENSING PROPORTIONING VALVE (LSPV)
	09922–10010	Variable Open Wrench	BRAKE MASTER LESS RESERVOIR TANK CYLINDER SUB–ASSY
	09990–00150	ABS Actuator Checker and Sub–harness	ABS & TRACTION ACTUATOR ASSY
	09990–00250	ABS Actuator Checker Sub–harness ”G”	ABS & TRACTION ACTUATOR ASSY
	09990–00300	ABS Actuator Checker Sub–harness ”I”	ABS & TRACTION ACTUATOR ASSY
	09990–00360	ABS Actuator Checker Sub–harness ”L”	ABS & TRACTION ACTUATOR ASSY

Recomended Tools

	09031–00040	Pin Punch .	VACUUM PUMP ASSY(14B, 15B–FTE) VACUUM PUMP ASSY(S05C–B, S05C–TA, S05C–TB)
	09905–00013	Snap Ring Pliers	VACUUM PUMP ASSY(14B, 15B–FTE) VACUUM PUMP ASSY(S05C–B, S05C–TA, S05C–TB) VACUUM PUMP ASSY(W04D–J)

Equipment

Brake drum gauge	
Dial indicator or dial indicator with magnetic base	
Micrometer	
Press	
Ruler	
Torque wrench	
Vernier calipers	

Lubricant

Item	Capacity	Classification
Brake fluid	–	SAE J 1703 or FMVSS No. 116 DOT 3