



MANUAL TRANSMISSION/TRANSAXLE


022EX–01

PREPARATION

SST

	09308–00010	Oil Seal Puller	REAR BEARING RETAINER OIL SEAL
	09316–60011	Transmission & Transfer Bearing Replacer	REAR BEARING RETAINER OIL SEAL
	(09316–00011)	Replacer Pipe	REAR BEARING RETAINER OIL SEAL
	(09316–00041)	Replacer "C"	REAR BEARING RETAINER OIL SEAL

Recomended Tools

	09905–00013	Snap Ring Pliers	FLOOR SHIFT ASSY

Equipment

Torque wrench	

Lubricant

Item	Capacity	Classification
Manual transmission oil (M150/153)	3.2 liters (3.4 US qts, 2.8 Imp. qts)	API GL–4 or GL–5 SAE 75W–90
Manual transmission oil (H350/H351/H260)	4.2 liters (4.4 US qts, 3.7 Imp. qts)	API GL–4 or GL–5 SAE 75W–90