





















MANUAL STEERING




022EI–01

PREPARATION



SST

	09611–36020	Tie Rod End Puller	STEERING LINKAGE(STANDARD CAB MODELS) STEERING LINKAGE(WIDE CAB MODELS)
	09612–65014	Steering Worm Bearing Puller	STEERING GEAR HOUSING ASSY
	(09612–01030)	Claw ”C”	STEERING GEAR HOUSING ASSY
	(09612–01040)	Claw ”D”	STEERING GEAR HOUSING ASSY
	09616–00011	Steering Worm Bearing Adjusting Socket	STEERING GEAR HOUSING ASSY
	09617–60010	Worm Bearing Adjusting Screw Lock Nut Wrench	STEERING GEAR HOUSING ASSY
	09628–00011	Ball Joint Puller	STEERING LINKAGE(STANDARD CAB MODELS) STEERING LINKAGE(WIDE CAB MODELS)
	09628–62011	Boll Joint Puller	STEERING LINKAGE(STANDARD CAB MODELS) STEERING LINKAGE(WIDE CAB MODELS)
	09950–40011	Puller B Set	STEERING GEAR HOUSING ASSY
	(09951–04010)	Hanger 150	STEERING GEAR HOUSING ASSY
	(09951–04020)	Hanger 200	STEERING GEAR HOUSING ASSY
	(09952–04010)	Slide Arm	STEERING GEAR HOUSING ASSY

	(09953–04020)	Center Bolt 150	STEERING GEAR HOUSING ASSY
	(09954–04010)	Arm 25	STEERING GEAR HOUSING ASSY
	(09955–04031)	Claw No.3	STEERING GEAR HOUSING ASSY
	(09955–04051)	Claw No.5	STEERING GEAR HOUSING ASSY
	(09958–04010)	Holder (J)	STEERING GEAR HOUSING ASSY
	(09958–04011)	Holder	STEERING GEAR HOUSING ASSY
	09950–60010	Replacer Set	STEERING GEAR HOUSING ASSY
	(09951–00180)	Replacer 18	STEERING GEAR HOUSING ASSY
	(09951–00310)	Replacer 31	STEERING GEAR HOUSING ASSY
	(09951–00520)	Replacer 52	STEERING GEAR HOUSING ASSY
	(09951–00550)	Replacer 55	STEERING GEAR HOUSING ASSY
	(09952–06010)	Adapter	STEERING GEAR HOUSING ASSY
	09950–70010	Handle Set	STEERING GEAR HOUSING ASSY

	(09951–07100)	Handle 100	STEERING GEAR HOUSING ASSY
	(09951–07200)	Handle 200	STEERING GEAR HOUSING ASSY
	09960–10010	Variable Pin Wrench Set	STEERING GEAR HOUSING ASSY
	(09962–01000)	Variable Pin Wrench Arm Assy	STEERING GEAR HOUSING ASSY
	(09963–00600)	Pin 6	STEERING GEAR HOUSING ASSY
	(09963–01000)	Pin 10	STEERING GEAR HOUSING ASSY

Recomended Tools

	09025–00010	Torque Wrench (30 kgf–cm)	STEERING GEAR HOUSING ASSY
	09200–00010	Engine Adjust Kit	STEERING GEAR HOUSING ASSY

SSM

	08833–00080	Adhesive 1344 THREE BOND 1344 LOCTITE 242 or equivalent	STEERING GEAR HOUSING ASSY

Equipment

Caliper gauge	
Chisel	
Dial indicator	
Micrometer	
Press	
Torque wrench	