






# SUPPLEMENTAL RESTRAINT SYSTEM



022F0–01

## PREPARATION

### SST

| | | | |
|---|---|---|---|
|  | 09082–00700 | SRS Airbag Deployment Tool | HORN BUTTON ASSY |
|  | 09082–00760 | Airbag Deployment Wire<br>Sub–harness No.4 | HORN BUTTON ASSY |
|  | 09950–50013 | Puller C Set | SPIRAL CABLE<br>AIRBAG SENSOR ASSY |
|  | (09951–05010) | Hanger 150 | SPIRAL CABLE<br>AIRBAG SENSOR ASSY |
|  | (09952–05010) | Slide Arm | SPIRAL CABLE<br>AIRBAG SENSOR ASSY |
|  | (09953–05020) | Center Bolt 150 | SPIRAL CABLE<br>AIRBAG SENSOR ASSY |
|  | (09954–05021) | Claw No.2 | SPIRAL CABLE<br>AIRBAG SENSOR ASSY |

### Recomended Tools

| | | | |
|---|---|---|---|
|  | 09042–00010 | Torx Socket T30 | SPIRAL CABLE SUB–ASSY<br>HORN BUTTON ASSY<br>AIR BAG SENSOR ASSY NO.2 |
|  | 09042–00020 | Torx Socket T40 | AIR BAG SENSOR ASSY NO.2 |

### Equipment

| | |
|---|---|
| Torque wrench | |
| Bolt Length: 35.0 mm (1.387 in.) Pitch: 1.0 mm (0.039 in.)<br>Diam.: 6.0 mm (0.236 in.) | Airbag disposal |
| Tire Width: 185 mm (7.28 in.) Inner diam.: 360 mm (14.17 in.) | Airbag disposal |
| Tire with disc wheel Width: 185 mm (7.28 in.)<br>Inner diam.: 360 mm (14.17 in.) | Airbag disposal |
| Vinyl bag | Airbag disposal |