# SEAT BELT

## TORQUE SPECIFICATION

030Z0–02

| Part Tightened | | N·m | kgf·cm | ft·lbf |
|---|---|---|---|---|
| FRONT SEAT BELT (3P ELRx2, NRx1) | | – | – | – |
| Front seat outer belt assy (Driver side) x Body | Retractor side bolt | 42 | 420 | 30 |
| | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat outer belt assy (Passenger side) x Body | Retractor side bolt | 42 | 420 | 30 |
| | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat inner belt assy (Driver side) x Front seat | | 40.2 | 410 | 30 |
| Front seat lap type belt assy center x Body | | 42 | 420 | 30 |
| Front seat inner belt assy x Body | | 42 | 420 | 30 |
| FRONT SEAT BELT (3P ELRx2) | | – | – | – |
| Front seat outer belt assy (Driver side) x Body | Retractor side bolt | 42 | 420 | 30 |
| | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat outer belt assy (Passenger side) x Body | Retractor side bolt | 42 | 420 | 30 |
| | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat inner belt assy (Driver side) x Front seat | | 40.2 | 410 | 30 |
| Front seat inner belt assy x Body | | 42 | 420 | 30 |
| FRONT SEAT BELT (3P NRx2) | | – | – | – |
| Front seat outer belt assy (Driver side) x Body | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat outer belt assy (Passenger side) x Body | Shoulder side bolt | 42 | 420 | 30 |
| | Floor anchor side bolt | 42 | 420 | 30 |
| Front seat inner belt assy (Driver side) x Front seat | | 40.2 | 410 | 30 |
| Front seat inner belt assy x Body | | 42 | 420 | 30 |