

057EN–02


LOCATION



Y F42510

F45228


LHD
R/B No. 1 and J/B No. 1
Combination Meter Assy
(ABS Warning Light)
(Parking Brake Warning Light)
Master Cylinder
Pressure Sensor
GAUGE Fuse
ECU–IG Fuse
Vacuum Sensor
Skid Control ECU
DLC3
Stop Lamp Switch Assy
Parking Brake Switch
Y F42497
F45229


R/B No. 1 and J/B No. 1
GAUGE Fuse
ECU–IG Fuse
Combination Meter Assy
(ABS Warning Light)
(Parking Brake Warning Light)
Master Cylinder
Pressure Sensor
Vacuum Sensor
DLC3
Stop Lamp Switch Assy
Skid Control ECU
Parking Brake Switch
F45230