EASY & SMOOTH START SYSTEM AND BRAKE LOCK SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

05BBF–01

HINT:

Troubleshoot in accordance with the procedures on the following pages.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–280)

3	CHECK AND CLEAR DTCS (See page 05–270)

4	PROBLEM SYMPTOM CONFIRMATION

- SYMPTOM DOES NOT OCCUR: Go to step 5
- SYMPTOM OCCURS: Go to step 6

5	SYMPTOM SIMULATION (See page 01–17)

6	DTC CHECK (See page 05–270)

- DTC IS NOT OUTPUT: Go to step 7
- DTC IS OUTPUT: Go to step 8

7	PROBLEM SYMPTOMS TABLE (See page 05–280)

- CHECK FOR FLUID LEAKAGE AND Go to step 10

8	DTC CHART (See page 05–276)

9	CIRCUIT INSPECTION (See page 05–282)

10	IDENTIFICATION OF PROBLEM

11	REPAIR

12	CONFIRMATION TEST

END

Fail–safe function:
If a failure occurs in the easy & smooth start system and the brake lock system, the ES warning lamp will light up and the ES operation will be prohibited.