PARKING BRAKE SYSTEM

PROBLEM SYMPTOMS TABLE

330BE–01

Use the table below to help you find a cause of the problem. The numbers indicate the priority of a likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspected Area	See Page
Brake drag	1. Parking brake lever travel (Out of adjustment)	33–3
	2. Parking brake wire (Sticking)	33–3
		33–4
		33–6
	3. Parking brake shoe clearance (Out of adjustment)	33–11
	4. Parking brake shoe lining (Cracked or distorted)	33–11
	5. Tension or return spring (Damaged)	33–11