5004P–02

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to help you find the cause of the problem. The numbers indicate the possibility of the problem in descending order. Check each part in the order shown. If necessary, repair or replace these parts.

Symptom	Suspected Area	See Page
Hard steering	1. Tires (Improperly inflated)	28–1
	2. Power steering fluid level (Low)	51–3
	3. Front wheel alignment (Incorrect)	26–2
	4. Steering system joints (Worn)	–
	5. Steering column (Binding)	50–8
	6. Power steering vane pump 14B	51–10
	15B–FTE	51–27
	S05C–B, S05C–TA, S05C–TB	51–27
	W04D–J	51–37
	7. Power steering gear	51–47
Poor return	1. Tires (Improperly inflated)	28–1
	2. Front wheel alignment (Incorrect)	26–2
	3. Steering column (Binding)	–
	4. Power steering gear	51–47
Excessive play	1. Steering system joints (Worn)	–
	2. Intermediate shaft, Sliding yoke (Worn) B–TYPE	30–22
	LE–TYPE	30–29
	3. Front wheel bearing (Worn) Disc Brake	30–34
	5–Bolts Drum Brake	30–40
	6–Bolts Drum Brake	30–45
	4. Power steering gear	51–47
Abnormal noise	1. Power steering fluid level (Low)	51–3
	2. Steering system joints (Worn)	–
	3. Power steering vane pump 14B	51–10
	15B–FTE	51–27
	S05C–B, S05C–TA, S05C–TB	51–27
	W04D–J	51–37
	4. Power steering gear	51–47