
5004Q–02

# ON–VEHICLE INSPECTION




**1. CHECK STEERING WHEEL FREE PLAY**

(a) Stop the vehicle and face the tires straight ahead.

(b) Gently move the steering wheel up and down with your hand, and check the free play.

**Maximum free play: 25 mm (0.98 in.)**