
650EK–02

ADJUSTMENT



1. ADJUST FOG LAMP AIM ONLY

(a) Adjust the fog lamp aim by moving the aiming screw in the vertical direction.