
66061–03

ON–VEHICLE INSPECTION



1. CHECK WASHER MOTOR

(a) Pour the water into the washer jar with the washer motor installed to the washer jar.

(b) Connect the positive (+) lead from the battery (+) to terminal 2 of the washer motor and the negative (–) lead to terminal 1 of the washer motor. Check that the water comes out from the washer jar.

If the result is not as specified, replace the motor.