IGNITION SYSTEM

PROBLEM SYMPTOMS TABLE

8002F–03

Symptom	Suspected Area	See Page
Ignition or starter switch can not be set to each position.	1. AM1 fuse 2. AM2 fuse 3. Ignition or starter switch 4. Power source circuit	– – 80–2 –