





STARTING & CHARGING


022DM–01

PREPARATION

SST

	09285–76010	Injection Pump Camshaft Bearing Cone Replacer	STARTER ASSY(14B)
	09286–46011	Injection Pump Spline Shaft Puller	STARTER ASSY(14B)
	09810–38170	Starter Magnet Switch Nut Wrench 17	STARTER ASSY(14B)
	09820–00021	Alternator Rear Bearing Puller	GENERATOR ASSY(14B)
	09820–00031	Alternator Rotor Rear Bearing Replacer	GENERATOR ASSY(14B)
	09820–63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY(14B)
	09950–60010	Replacer Set	GENERATOR ASSY(14B)
	(09951–00220)	Replacer 22	GENERATOR ASSY(14B)
	(09951–00520)	Replacer 52	GENERATOR ASSY(14B)
	09950–70010	Handle Set	GENERATOR ASSY(14B)
	(09951–07100)	Handle 100	GENERATOR ASSY(14B)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	STARTER ASSY(14B) GENERATOR ASSY(14B)

Equipment

Dial indicator with magnetic base	
Press	
Pull scale	
Magnetic finger	Magnet starter switch assy
Sandpaper #400	Starter armature assy
Soldering iron	
Torque wrench	
Vernier calipers	
Vise	