
# INTAKE


## PREPARATION

023W6–01

### SST

| | | | |
|---|---|---|---|
|  | 09992–00242 | Turbocharger Pressure Gauge | TURBOCHARGER SYSTEM (N04C–TF) |

### Recomended Tools

| | | | |
|---|---|---|---|
|  | 09082–00040 | TOYOTA Electrical Tester | TURBOCHARGER SYSTEM (N04C–TF) |

### Equipment

| | |
|---|---|
| Torque wrench | |