

05L1W–01

LOCATION




ECM
DLC3
Idle Variable Resistor Switch
R/B No. 1 and J/B No. 1
● ST Fuse
Voltage Converter
P
A96459